

PNT FILLING INSTRUCTIONS

The PN1 Fill Panel does not have a regulator so it will fill to the maximum pressure in the storage tanks.

If you are filling a 3000 psi Marker tank do not exceed the rated pressure of the Marker tank!

Check the hydro date and the condition of the Marker tank before filling. Comply with all laws regarding filling tanks.

Do not fill a tank if the hydro date is past due or the tank is cracked or dented. Connect the Marker tank to the quick release located on the side of the Marker tank regulator.

Keep your face away from the fill panel and Marker tank!

Push the toggle valve in any direction to fill the marker tank.

Watch the pressure on the Marker tank and the gage on the panel so the maximum pressure is not exceeded.

Release the toggle vale and disconnect the tank.

